XiteSolutions
North America Inc

2015 XSG2NA-X2 Infotainment System Family with Rand McNally RV GPS



XSG2NA-X2L 10.4" Infotainment System

XSG2NA-X2DM 10.4" Dual Monitor Infotainment System







X2DM/L Features

- 10.4" Touch Screen Display
- Rand McNally RV GPS
- Rand McNally Wi-Fi Services (Optional)
- Dedicated 7" 2nd Monitor (DM model)
- Temperature/Compass Display (Optional)
- iPod and iPhone Audio playback
- SiriusXM - SXV200 Tuner
- GPS System Clock/DST/TZ set
- DVD/CD/USB Core Module
- House Mode A/V Distribution (Optional)
- Touch Screen Multi Camera Management with CVS Family Modules
- Camera Audio/Video Support
- Favorite Source Hot Key
- Integrated Bluetooth for HF calling, stream audio from device and many app sources
- AM/FM with RDS

XiteSolutions
North America Inc



XSG2NA-X2 7” Infotainment System







X2 Features

- 7” Touch Screen Display
- Rand McNally RV GPS
- Rand McNally Wi-Fi Services (Optional)
- 7” Passive 2nd Monitor (Optional)
- Temperature/Compass Display (Optional)
- iPod and iPhone Audio playback
- SiriusXM - SXV200 Tuner
- GPS System Clock/DST/TZ set
- DVD/CD/USB
- House Mode A/V Distribution (Optional)
- Touch Screen Multi Camera Management with CVS Family Modules
- Favorites Source Hot Key
- Camera Audio/Video support
- Integrated Bluetooth for HF calling, stream audio from device and many app sources
- Aux Output supporting Navigation and Camera display
- AM/FM with RDS

XiteSolutions
North America Inc



XSG2NA-X2S 6” Infotainment System







X2S Features

- 6” Touch Screen Display
- Rand McNally RV GPS
- Rand McNally Wi-Fi Services (Optional)
- 7” Passive Monitor (Optional)
- Temperature/Compass Display (Optional)
- iPod and iPhone Audio playback
- SiriusXM - SXV200 Tuner
- GPS System Clock/DST/TZ set
- Front access DVD/CD/USB and 3.5mm audio inputs
- House Mode A/V Distribution (Optional)
- Touch Screen Multi Camera Management with CVS Family Modules
- Favorite Source Hot Key
- Camera Audio/Video Support
- Quick Camera View Button
- Integrated Bluetooth for HF calling, stream audio from device and many app sources
- Aux Output for Entertainment Sources
- AM/FM with RDS

XSG2NA-X2 Family Quick Start Guide

This Quick Start Guide is intended to provide basic instructions to begin using your Infotainment Center.
Failure to properly focus on the operation of your motor vehicle can result in death, serious injury and property damage. The Infotainment Center should never be used at a time or in a manner that distracts you from properly focusing on operation of the motor vehicle in which it is installed. **Please review all disclaimers, warnings and detailed operating instruction in your Owner's Manual prior to using your Infotainment Center.**

Hardware Buttons

XSG2NA-X2DM/L



1. Bluetooth Microphone
2. PWR. Press to enter/exit standby
3. MENU. Press to access Main Menu
4. DIM. Press to increase screen brightness. Changes saved for both day/night modes
5. VOL +/-. Press to adjust volume
6. NAVI, Press to enter/exit navigation display. Press and hold to only hear navigation prompts (mutes current audio source)
7. Favorite Source Hot Key
8. MUTE. Press to mute all audio
9. IR Receiver for Remote Control Operation

XSG2NA-X2



1. Bluetooth Microphone
2. PWR. Press to enter/exit standby. Press and hold to MUTE
•
3. MODE. Press to access Main Menu
4. DIM. Press to increase screen brightness. Changes saved for both day/night modes
5. VOL +/-. Press to adjust volume
6. Favorite Source Hot Key
7. NAVI. Press to enter/exit navigation display. Press and hold to only hear navigation prompts (mutes current audio source)
8. EJECT. Press drop down screen for access to optical drive
9. IR Receiver for Remote Control Operation

XSG2NA-X2S



1. DVD/CD Eject (left) and disc slot (right)
2. MENU. Press to access Main Menu
3. NAVI, Press to enter/exit navigation display. Press and hold to only hear navigation prompts (mutes current audio source)
4. CAM. Press to access manual Camera view.
5. Favorite Source Hot Key
6. Power/Volume Knob. Turn to adjust volume.
7. Press once to Mute. Press and hold to enter/exit Standby
• RV GPS SD Card Slot. For Navigation Only
8. Aux Inputs. USB and 3.5mm audio ports
9. Bluetooth Microphone

Header Information

1. Audio Source Icon. (Tap to access Main Menu)
2. Outside Temperature Display (Optional)
3. Compass Heading (Optional)
4. Current Time
5. Bluetooth Connection Status



Accessing the Infotainment Features

1. To access the Main Menu or change screens, tap source ***Icon*** in top left corner.
2. Select a new media source. Audio from current source will continue to play during navigation or camera video display
3. Select ***Aux Zone*** to change display source on 2nd monitor output
4. Select ***Settings*** to change system/source options. To change source settings, go to the audio source you wish to change then go into settings. Select the source on the bottom right.
5. Touch Page Number to go to next ***Settings*** *Page*







Source Quick Tips

- **RADIO**: Tap ***AS*** button to Auto Store 6 Pre-sets of the available Radio Stations in your area.
- **iPod**: Connect your iPod/iPhone using your USB/iPod cable to listen to audio tracks on you Apple device. (see Dealer for location)
  - Use the control buttons and Menu to find tracks/playlists. Tap your selection.
- **SiriusXM**: Note: A subscription is required to enjoy SiriusXM Satellite radio. Please see your Owner's Manual or go to www.siriusxm.com (in Canada www.xmradio.ca) and click ACTIVATE RADIO.
  Features of SiriusXM:
  - **Replay**: Press **Replay** to listen up to 1 hour of previous audio on your current channel. (may vary by tuner model)
  - **Song/Artist Alerts**: Store up to 50 of your favorite Songs and Artists. Tap **FUNC > ALERT+**. You will be notified when saved alerts are playing on other channels.
  - **My Favorites**: Create your own virtual category of your favorite channels. Tap **CAT+** to save the current Channel as a favorite. To use **MY FAVORITES** Category, Tap **CAT** and Scroll down to **MY FAVORITES** and Tap. Choose a Channel.
  - **Automatic Mature Channel** and User defined **Channel Locking**. Please see Owner's Manual
- **On-Screen Manual Camera Selection**: Tap **Camera** Icon to go to Manual Camera view. Tap screen center to bring up camera icons. Tap the camera you wish to view. To hear **Rear Camera Audio** tap the **Speaker** icon.
- **Bluetooth**: To connect you phone Tap **NEW** button and follow your phone prompts and instructions. After connection you can:
  - Make Hands Free Calls
  - Download your phonebook form you cell phone*
  - Listen to your stored audio tracks*
  - Stream and control audio from many of today's popular Apps using the audio controls on-screen*
- **DVD/CD/USB:** Insert your disc or USB device and use the on-screen controls to enjoy your media.**
- **RV GPS Navigation**: Please see your separate RV GPS Quick Start Guide to help you get on your way and begin using all the features this Industry Leading navigation software from Rand McNally has to offer
- **Wi-Fi:** Wi-Fi ready. Connect to Rand McNally weather/traffic premium services.

* Pending device limitations from your phone/hardware manufacturer. Please see individual device manuals
** Please see Owner's Manual for a full list of supported file and disc formats.

For Support:

RiverPark Inc
www.riverparkinc.com
navi@riverparkinc.com
800-442-7717

XiteSolutions North America Inc.
support@xsna.ca
www.xsna.ca

Rand McNally
www.randmcnally.com/support
800-333-0136

Link to online manuals: http://riverparkinc.com/index.php?route=information/downloads&manufacturer_id=22